



Cisco Aironet Power Injector (AIR-PWRINJ5) Installation Guide

First Released: January 31, 2013

Preface

The Cisco Aironet Power Injector (AIR-PWRINJ5) increases wireless LAN deployment flexibility of Cisco Aironet Access Points by providing an alternative powering option to local power, inline power-capable multiport switches, and multiport power patch panels.

The single-port Cisco Aironet Power Injector provides 802.3af power and data signal, sending both to the Cisco Aironet Access Point.

The power injectors provide up to 15.4 W over the unused wire pairs of a Category 5 or better Ethernet cable, supplying enough power for a distance of 328 ft. (100 m) on the Cisco Aironet 1040, 1140, 1260, 2600, and 3500 Series Access Points. While it can also support the Cisco Aironet Series 3600 Access Points when modules are not being used, it is recommended to use the AIR-PWRINJ4= power injector instead for the 3600 series, as it has sufficient power to supply to the AP and any installed modules.

This guide covers the following Cisco Aironet Power Injector:

- Cisco Aironet Power Injector (AIR-PWRINJ5)

Cisco Aironet Power Injector

The Cisco Aironet Power Injector provides both power and data to a connected Cisco Aironet Access Point. The device serves the following functions:

- It provides Category 5 or better Ethernet media to the access point.
- It uses wires in an Ethernet cable to supply inline 15.4 W power to an access point. The power injector provides an easy and economical way to provide data and power to an access point located in areas where power is not available.

The power injector is used with the following Cisco Aironet Series Access Points:

- 1040 series access points



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- 1140 series access points
- 1260 series access points
- 1600 series access points
- 2600 series access points
- 3500 series access points


A Category 5 or better Ethernet cable connects the injector to a 10/100/1000 Ethernet switch, hub, or network, and another cable carries power and data to the access point's WAN Ethernet port. The power injector's built-in power supply has a C14 connector that connects to a wall outlet or power strip. The power injector connects to a wall outlet or power strip.

**Caution**

To avoid overheating and possible failure, do not stack or tie together (bundle) the power injector and its AC power cable.

Figure 1 shows the key features of the power injector.

Figure 1 Cisco Aironet Power Injector (AIR-PWRINJ5) Features




1	Status LED	3	AP Connector Port
2	Switch Connector Port	4	C14 Power Connector

The Status LED indicates the following system status events:

- AC Power - The LED blinks green at approximately 1.5 times per second to indicate that the Power Injector is powered ON and ready for connection.
- AP Power - The LED lights solid green to indicate that a valid IEEE 802.3af load (AP) is detected and powered ON.
- Invalid load connected or Fault: The LED rapidly blinks green at 10 times per second to an invalid load connected or a Fault. In these conditions the AP has not been powered on. This occurs for 2 seconds for normal error delay, and the detection process will automatically start again after 2.2 seconds unless there is a “restart after disconnect condition” set during the initial configuration.

Figure 2 shows a typical installation scenario.

Figure 2 Power Injector AIR-PWRINJ5 Installation Scenario



Unpacking the Power Injector

The typical power injector package contains the following items:

- Power injector
- Power cord
- URL Pointer Card and China RoHS Statement

If any item is missing or damaged, contact your Cisco representative or reseller.

Additional Requirements

Use the power cord that shipped with your power injector to supply power for the injector. If you install the access point in an environmental air space such as above a suspended ceiling, check national and local safety codes to make sure that the Ethernet cable you connect to the unit meets applicable standards.



Note The AIR-PWRINJ5 is not plenum and should not be installed in the plenum airspace.



Note The maximum distance that is supported for in-line power is 328 ft. (100 m), including the length of the 6.5-ft. (2-m) Ethernet cable provided with the power injector.

Installing the Power Injector

Follow these steps to install the power injector:

1. Plug a Category-5 Ethernet cable into the port on the power injector labeled *AP*.

2. Plug the other end of the Ethernet cable into the WAN uplink Ethernet port of the access point.
3. Plug a Category-5 Ethernet cable into the port on the power injector labeled *Switch*.
4. Plug the other end of the Ethernet cable into your 10/100/1000 Ethernet switch, hub, or network.
5. When power is applied, the Status LED blinks green at approximately 1.5 times per second. When the AP is detected, the Status LED glows solid green. If the power injector is connected incorrectly, the Status LED blinks green at 10 times per second.
6. Secure the power injector by mounting it to a vertical or horizontal surface using the mounting keyholes on the bottom of the unit.

Mounting Instructions

You can mount the power injector to most vertical or horizontal surfaces using the mounting tabs on the top right and bottom left of the unit.

Using the Mounting Tabs

To mount the power injector to a vertical or horizontal surface using the mounting tabs, you will need the following parts and tools:

- Two #6 plastic wall anchors if mounting to a drywall surface
- Two #6 x 1-in. (2.5 cm) sheet-metal screws
- A drill and a 3/16-in (0.48-cm) drill bit
- A Phillips head screw driver
- A small hammer

Follow these steps to mount the power injector:

1. Using the holes in the power injector mounting tabs as a template, mark the locations on the surface where you will drill the holes for the wall anchors or screws.
2. Drill a 3/16-in. (4.7-mm) hole at each marked location.
3. If you are using #6 wall anchors, use a hammer to install them in the holes.
4. Hold the power injector to the wall and align the mounting tabs on the power injector with the screw holes.
5. Insert the #6 screws through the mounting tabs and into the holes in the wall or surface.
6. Use a Phillips head screwdriver to drive the screws into the surface.




Note If the power injector is not securely fastened, continue making small adjustments until you are satisfied.

Specifications

This table lists specifications for the power injectors:

Specification	AIR-PWRINJ5=
Electrical	802.3af compliant 15.4 W power
Connectors	2 RJ-45 10/100/1000 (Cat 5 or better Ethernet cable)
Dimensions (L, W, H)	165 mm x 65 mm x 36 mm (6.5 in x 2.6 in x 1.4 in)
Stacking restrictions	Do not stack. Do not bundle the power injector and AC power cable.

Mechanicals



Regulatory Information

The following information is for FCC compliance of Class B devices:

The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

Applicable Standards

Except where indicated, the Cisco Aironet Power Injector (AIR-PWRINJ5) meets the following standards:

- FCC Part 15.107 and 15.109 Class B
- ICES-003 Class B (Canada)
- AS/NZS 3548 Class B
- VCCI Class B
- EN 301.489-1 and 17
- EN 55022
- EN 55024
- EN 60950
- UL 60950
- CSA C22.2 No. 60950
- IEC 60950